


Spare parts list

118/4 Orchestra music stand

11842-000-02 - chrome stand, black wooden desk

*Rev07



Position	Description	Article No.	Quantity
1	Knurled screw without logo M6 x 22 mm	01-82-837-55	1
2	Clamping element with pin R6	01-86-620-55	1
3	Clamping element with pin R7,5	01-86-630-55	1
4	Allen screw M5 x 36 mm	03-02-176-29	3
5	Leg tube complete	6-21025-1-02	3
6	End cap	01-84-980-55	3
7	Square nut M5	03-08-210-29	3
8	Knurled screw with logo M6 x 22 mm	01-82-948-55	1
9	End tube with swivel head ø16 mm complete	6-11840-1-02	1
10	Knurled screw with logo M6 x 10 mm	01-82-936-55	2
11	Screw connection of the music desk	3-00-000-065	1
12	Tilt connector complete	6-11810-4-55	1
13	Music desk	03-55-175-00	1
14	Accessories bag connecting plate	3-00-000-134	1